

## LIUGONG PARTS

PART NAME	PART NUMBER
AIR FILTER ELEMENT	60C2472
AIR FILTER ELEMENT	40C5856
FUEL FILTER	SP133011
WATER SEPARATOR ELEMENT	53C0051
ELEMENT	53W0031
HYDRAULIC OIL	53C0375
COMBINATION LIGHT LF	32B0098
COMBINATION LIGHT RL	32B0099
FLOOD LIGHT	32B0026
WORKING LIGHT	32B078
ROTATING BEACON	32B0080
OIL SEAL 70*95*13	13B0169
STEERING AX	SP100585
OIL SEAL 90*115*12	SP104298
SEAL KIT BOOSTER	SP174305
PISTON	SP134119
CLAMP SEAL	SP173147
CLAMP SEAL	SP194882
THERMOSTER	SP171914
V BELT	SP132324
ELECTROMAGNET	SP170735
SIDE MIRROR	44D0050
KNUCLE BEARING	25B0177
KNUCLE BEARING	25B0091
KNUCLE BEARING	25B0005
PLANETARY GEAR	41A0002
SUN GEAR	41A0003
FLANGE	04A4228
BLOCK	16A5847
FLANGE	53A3090
ORING	12B0287
PRESSURE SWITCH	13C0243
INSERT VALVE	SP126904
PLANETARY GEAR SHAFT	60A0007

THRUST WASHER	56A0702
THRUST WASHER	SP100039
FUEL SENSOR LEVEL	30B0632
FUEL SENSOR LEVEL	30B0186
BUSHING	55A0281
BUSHING	54A0008
BUSHING	55A3506
BUSHING	55A6453
DOOR LOCK	48C1476
V SEAL	83A0338
V BELT	SP168469
V BELT	SP106340
ORING 475*7	12B0206
OIL SEAL	SP100214
OIL SEAL	
FUEL HOSE	06C6821
SPING	SP100200
OIL SEAL	13B1152
LINIG ANG CARRIER	SP184347
SHIMS	56A5314
SHIMS	56A4180
SHIMS	56A0003
SIMS	
HOSE	05C5371
FLEXIBLE SHAFT	23C0039
SEAL RING	84A2060
FLEXIBLE SHAFT	SP123338
FLEXIBLE SHAFT	54C0449
OIL PIPE	05C0825
BRAKE LINES	01C0528
BOLT	00A0356
ORING	12B0365
NUT	03B2075
CONNECTOR	00A4283
TEE	16A1000
PLUG	05A0083
THERMOSTER	SP129326

TAPPET	SP105108
WASHER	56A0378
SHIMS	20A2841
DUST RING	13B0196
DUST RING	35C0012
DUST RING	13B0258
SEAL RING	35C1677
SEAL RING	35C0012
SEAL RING	35C0013
ORING	12B0034
SEAL KIT	SP227235
SEAL KIT	SP201471
ROTARY BUCKET CYLINDER	SP239578
BUCKET CYLINDER KIT	34C6828
GEAR PUMP KIT	SP120111
SEAL KIT	SP120115
STEERKIT	SP201524
SPIDER	63A0005
FILLER CAP	53A0369
STEERING SEAL KIT	SP100585
DUST RING	13B0682
STEERING	SP131838
SEAL KIT	SP227234
PISTON	50A0263
OIL SEAL;	SP151742
SEAL KIT	SP227229
SEAL RING	35C0013
SEAL RING	35C0003
ROLLING NEEDLE	20B0001
OIL SEAL	13B1152
OIL SEAL	13B0169
STARTER	SP172424
STARTER	SP214608
ALTERNATOR	SP201244
WATERPUMP	SP214608
PUMP	SP105451
ELECTROMAGNET	SP190269

FILTER ASSY	53C1715
PILOT VALVE	12C4724
CONE	23B0023
DIRECTIONAL VALVE	SP184461
CYLINRICAL ROLLER BEARING	20V0010
CLUCTH ASSY	42C1912
DOMELIGHT	32B0359
GEAR PUMP	11C1813
FUEL PIPE	06C4789
OIL FILTER	53C0027
FRICTION PLATE	37C1093
LINER CYLINDER	SP1292581
LINER CYLINDER	SP241752
FUEL PRELIMINARY FILTER	SP107446
WATER SEPARATOR ELEMENT	53C0945
FUEL FILTER	40C7018
FUEL AND VEPOR	SP125965
OIL FILTER	SP134177
WATER SEPARATOR ELEMENT	53C0583
SECONDARY FUEL FILTER	SP133752
FILTER BOWL	SP128977
QUICKER COUPLER	13C0012
STOP VALVE	12C2378
VALVE ASSY	13C0059
PRESSURE TRANSMITTER	30B1042
HANDLE ASSY	24C1655
PRESSURE SWITCH	34B1072
PRESSURE SWITCH	30B1065
WATER FUEL SENSOR	08C4388
FAN BELT	SP100693
WASHER	26B0016
BALL JOINT	24C0373
BLADE SLIEDKIT	SP130216
REPAIRKIT	SP130214
TANDAM BUSH	SP115140
FLANGE	53A3090
MOTOR	11C0158

PUMP	11C0009P02
TRACK LINK	25C0688
INTAKE PIPE	71A1613
COUPLING	40C1261
CONTROLLER	37B1403
BUSHING	55A3483
BUSHING	55A3505
CONTROLLER	37B133*
T BUSHING	55A3482
T SLEEVE	55A3504
BUSHING	55A8530
BUSHING	55A4864
STEEL SLEVE	SP251126
STEEL SLEVE	SP25`1123
BUSHING	55A3517
HYDRAULIC FILTER	53C0515
HYDRAULIC FILTER	53C1486
BUCKET PIN	11D1740
H LINK PIN	60A5542
DIFFER	
PIN	11D0003X0
PIN	11D00993X0
PIN	11D1712X0
PIN	11D0635
PIN	11D1390
PIN	11D1820X0
PIN	11D1711X0
PIN	11D1382X2
PIN	11D0859X0
PIN	11D0792X0
PIN	11D1706
PIN	11D1391
PIN	11D001
PIN	11D1309X0
PIN	11D2228X0